YS-E600

Manual

EL

www.rami-yokota.com



Always take off the battery when adjusting the torque output with the relief valve on the impulse mechanism.

- Adjusting the tool's output with the relief valve, mechanical adjustment on the impulse mechanism.

- Rotate the main shaft until the adjust screw is visible, turn left to increase the torque output and turn right to decrease the torque output.
- Use the TF pin (2mm x 90mm, supplied with the tool in the box).

①	Relief adjust holes
②	Max side, increase torque
③	Min side, decrease torque

Relief valve adjustment

Συντήρηση

Ελέγξτε το εργαλείο συχνά για χαλαρές βίδες/συνδέσμους ή μέρη.

Μετράτε τις στροφές του εργαλείου συχνά, σε περίπτωση υψηλότερων ή χαμηλότερων στροφών από των αναγραφόμενων τεχνικών προδιαγραφών σταματήστε αμέσως τη χρήση του και επισκευάστε το.

Σε περίπτωση απώλειας δύναμης, επισκευάστε το εργαλείο.

Μόνο εξουσιοδοτημένο και εκπαιδευμένο τεχνικό προσωπικό επιτρέπεται να ρυθμίζει και να επισκευάζει το εργαλείο.

Σε περίπτωση που θέλετε να πετάξετε το εργαλείο, ακολουθήστε τον τοπικό κανονισμό έτσι ώστε να ανακυκλωθούν όσα πιο πολλά μέρη γίνεται. ΜΗΝ πετάξετε το εργαλείο στα σκουπίδια.

The tool should be maintained regularly to minimize the noise emission and occurring vibration.

The oil in the impulse unit must be regularly replaced. Preventive maintenance is important because if the oil is replaced too late the viscosity changes so the torque will decrease and damage may occur on the internal parts.

For Yokota Impulse wrenches the advice is to replace the oil after 250.000 cycles on hard joint, one cycle is 0,5 – 1 second impulsing. On soft joints, longer impulsing time per cycle, the oil must be changed earlier.

Oil replacement should only be carried out by trained qualified specialists.

www.rami-yokota.com

RAMI YOKOTA BV | DE RUYTERKADE 120 | 1011 AB AMSTERDAM | THE NETHERLANDS
Tel. +31-(0)20-5318800 E-mail info@rami-yokota.com www.rami-yokota.com