


# RRI-50RTA IMPULSE WRENCH



Edition:07A

| Index No. | Part No.     | Description            | Q'ty | Index No. | Part No.  | Description                                               | Q'ty |
|-----------|--------------|------------------------|------|-----------|-----------|-----------------------------------------------------------|------|
| 1         | 747-002      | Spring Holder          | 1    | 51        | I40S-306  | Lock Nut                                                  | 1    |
| 2         | I50R-706     | Lock Nut               | 1    | 52        | 00-2348   | Ball Bearing                                              | 1    |
| 3         | 00-41134     | O-Ring                 | 1    | 53        | 00-3324   | Spring Pin                                                | 1    |
| 4         | 00-2358      | Ball Bearing           | 1    | 54        | I40S-302  | Cylinder                                                  | 1    |
| 5         | I50R-711     | Washer                 | 1    | 55        | 00-3326   | Spring Pin                                                | 1    |
| 6         | 00-3813      | Steel Ball             | 3    | 56        | I40S-303  | Rotor                                                     | 1    |
| 7         | I50RD-705    | Shaft Gear             | 1    | 57        | I40S-304  | Rotor Blade                                               | 9    |
| 8         | I50R-707     | Shaft                  | 1    | 58C       | I50R-305  | Rear Plate                                                | 1    |
| 9         | 00-2357      | Ball Bearing           | 1    | 59        | 00-2356   | Ball Bearing                                              | 1    |
| 10        | I90-410      | Plug                   | 1    | 60        | I40S-310  | Air inlet Plate                                           | 1    |
| 11        | 00-4153      | O-Ring                 | 1    | 61        | 305F-034  | Spring                                                    | 1    |
| 12        | I50R-701     | Angle Housing          | 1    | 62        | IS40S-502 | F/R Valve                                                 | 1    |
| 13        | 00-0605      | Set Screw              | 1    | 63        | 00-41146  | O-Ring                                                    | 1    |
| 14        | I50R-704     | Main Shaft Gear        | 1    | 64        | 00-4121   | O-Ring                                                    | 1    |
| 15        | I50R-712     | Washer                 | 1    | 65        | IS40S-312 | Valve Washer                                              | 1    |
| 16        | 00-2352      | Ball Bearing           | 2    | 66        | 00-3824   | Steel Ball                                                | 1    |
| 17        | I50R-709     | Lock Nut               | 1    | 67        | IS40S-313 | Spring                                                    | 1    |
| 18        | I50R-702     | Lock Nut               | 1    | 68        | IS40S-311 | Valve                                                     | 1    |
| 19        | I50R-708     | Anvil Collar           | 1    | 69        | 00-41125  | O-Ring                                                    | 1    |
| 20        | 00-3430      | Pin                    | 1    | 70        | I40S-309  | Seat                                                      | 1    |
| 21        | I50R-201     | Front Housing          | 1    | 71        | I40S-101B | Motor Housing                                             | 1    |
| 22        | I40S-202     | Bushing                | 1    | 72        | 00-0507   | Screw                                                     | 1    |
| 23        | I40S-424     | Washer                 | 1    | 73        | I40S-503  | Regulator Knob                                            | 1    |
| 24        | I40S-401     | Pulse Cylinder Housing | 1    | 74        | I40S-102  | Hanger                                                    | 1    |
| 25        | 00-41127     | O-Ring                 | 3    | 75        | I40S-509  | Bushing                                                   | 1    |
| 26        | I70-410      | Oil Plug               | 1    | 76        | IS40S-510 | Pin                                                       | 1    |
| 27        | 00-41113     | O-Ring                 | 3    | 77        | I40S-504  | Trigger                                                   | 1    |
| 28        | 00-3318      | Spring Pin             | 2    | 78        | I40S-108  | Bushing                                                   | 2    |
| 29F       | I40S-403-B   | Front Plate Cover      | 1    | 79        | 00-3306   | Spring Pin                                                | 1    |
| 30        | I40S-408     | Front Plate            | 1    | 80        | I40S-103  | Rubber                                                    | 1    |
| 31        | 00-2602      | X-Ring                 | 1    | 81        | I40S-508  | Bushing                                                   | 1    |
| 32        | I50R-405     | Main Shaft             | 1    | 82        | 305C-021  | Valve Stem                                                | 1    |
| 33B       | I40S-452     | Roller                 | 2    | 83        | I40S-507  | Spring                                                    | 1    |
| 34B       | I40S-406-B   | Drive Blade            | 2    | 84        | I40S-601  | Muffler                                                   | 1    |
| 35        | I40S-407     | Spring                 | 2    | 85        | I40S-603  | Exhaust Deflector                                         | 1    |
| 36B       | IS40-450     | Block Valve            | 1    |           | I40S-604A | Air Inlet 1/4"PF-19                                       |      |
| 37GA      | I80-411      | Adjust Screw           | 1    | 86        | I40S-604B | Air Inlet 1/4"PT-19                                       | 1    |
| 38F       | IS40S-412-C  | Valve                  | 1    |           | I40S-604C | Air Inlet 1/4"NPT-18                                      |      |
| 39        | 00-41130     | O-Ring                 | 1    | 87        | 00-3509   | Snap Ring                                                 | 1    |
| 40F       | IS50RD-425-C | Spring                 | 1    | 88C       | 00-41173  | O-Ring                                                    | 2    |
| 41        | 00-3435      | Pin                    | 2    | 89C       | I40S-453  | Spring                                                    | 1    |
| 42        | 00-3436      | Pin                    | 1    | 90C       | I40S-454  | Block Cap                                                 | 1    |
| 43C       | I40S-404-B   | Pulse Cylinder         | 1    | 91F       | I40-409   | Back Up Ring                                              | 1    |
| 44        | 00-3407      | Pin                    | 2    | 92GA      | I80-422   | Back Up Ring                                              | 1    |
| 45F       | IS40S-415-C  | Rear Plate             | 1    | ※         | IS50RDRK  | Repair kit :Index No-27(2);25(2);31;35(2);88C(2);91F      |      |
| 46        | I40S-423     | Washer                 | 1    | ※         | IS50RDSK  | Service kit :Index No-7; 14; 30; 32; 33B(2); 34B(2); 45F; |      |
| 47C       | IS40S-421    | Pressure Valve         | 2    |           |           | 57(9); 67; 81; 82; 83                                     |      |
| 48        | IS40S-314    | Shut Off Stem          | 1    |           |           |                                                           |      |
| 49        | IS40S-317    | Spring                 | 1    |           |           |                                                           |      |
| 50        | I40S-402     | Lock Nut               | 1    | ※         | I40-451   | Impulse Oil                                               |      |

★Pulse unit includes:

Index No : 24,25,26,27,28,29F,30,31,32,33B,34B,35,36B,37GA,38F,39,40F,41,42,43C,44,45F,47C,50,88C,89C,90C,91F,92GA