



■Parts for Motor Case


No.	Name of parts	Per set	parts No.
M	Motor Case Assy.	1set	0483 0011 0099
※※	M1 Motor Case Assy.1	1set	0483 0011 0069
	(a) Motor Case A	1	0484 0011 0001
	(b) Motor Case B	1	0484 0011 0002
	(c) Motor Case C	1	0480 0011 0003
	(d) Lamp Holder A	1	0484 0959 0001
	(e) Lamp Holder B	1	0484 0959 0002
	(f) Slide Cover	1	0460 0035 0000
	(g) Screw M3X16	7	9540 1018 0000
	(h) Motor Assy.	1set	0482 0330 0299
M2	Fan Protector	1	0484 0363 0000
M3	Fan Assy.	1set	0484 1556 0099
M4	Rubber Packing	1	0446 0359 0000
M5	Screw M3X16	2	9410 2056 0000
M6	Ferrite Core GTR-13-7-6	1	8541 4009 0000
M7	Powersupply Basic Assy.	1set	0480 0195 0099
M8	Screw B-0306-S1	3	9410 4002 0000
M9	Harness A	1	0460 0208 0001
M10	Control Basic Assy.	1set	0483 1608 0099
M11	O-Ring S6	2	9010 4026 0000
M12	Rubber Sheet	1	0480 1626 0000
M13	Connector Basic	1	0460 1624 0000
M14	Screw M3X8	2	9540 1021 0000
M15	Harness B	1	0460 0208 0002
M16	Harness C	1	0480 0208 0003
M12	Rubber Sheet	1	0480 1626 0000
M17	Wireless Substrate	1	0480 1533 0000
M18	Seal A	1	0446 1513 0001
M19	Throttle Knob Assy.	1set	0446 0153 0199
M20	Spring 7.5X26	1	8020 1449 0000
M21	Spring 3.5X23	1	8020 1450 0000
M22	Reverse Lever Assy.	1	0446 0007 0099
M23	Reverse Lever Spring	1	0446 1615 0000
M24	Screw M2.6X5	1	9540 1019 0000
M25	Binding Band (CV-70N)	4	9790 1008 0000
Optional Accessories			
9	Protector (for BPL-1820)	1	0446 0029 0001
10	Battery Pack BPL-1820	1	0446 1521 0000
	Battery Charger BC2075MX	1	0446 1606 0001
	Power Cord 1.5M (Domestic)	1	8521 0008 0000
	Power Cord 2.0M (R. Pin for Europe)	1	8521 0009 0000
	Power Cord 1.5M <VM0760-VM0339> for China	1	8521 0029 0000
	Power Cord 1.5M <VM0228A-VM0296> for US	1	8521 0032 0000
	Power Cord 1.5M <VM0773-VM0776> for India	1	8521 0033 0000
	Hanger	1	0446 0017 0000
	Hanger Clip	1	0446 1801 0000
	Hanger A	1	0446 0017 0001
	Hanger Clip A	1	0446 1801 0001

※ 1 Please replace the Motor Case(A) and the Motor Case(B) as a unit.

Battery System Wrench
with built-in angle sensor

MODELS (YES.No.)	TOOL No.
YS-Z800 (00)	0483 0000 0000
YS-Z800A (00)	0483 0000 0001

■Exploded View of Motor Case




Parts for Liner Case

No.	Name of parts	Per set	parts No.
L	Liner Case Assy.	1set	0445 0422 0099
L1	Liner Case	1	0193 0422 0000
L2	O-Ring 1.78×29.87×33.43	1	9011 2003 0000
L3	Liner Cap	1	0186 0423 0000
L4	Liner Upper Plate	1	0186 0424 0000
L5	O-Ring 1.78×26.7×30.26	1	9011 6064 0000
L6	Liner Assy.	1set	0193 0425 0099
	(a) Liner	1	0193 0425 0000
	(b) Pin 2×4.8	4	8052 1041 0000
L7	Relief Valve	1	0445 0245 0000
L8	Pin 1.5X4	1	8051 1314 0000
L9	Liner Shaft	1	0445 0796 0000
L10	Blade	2	0352 0719 0000
L11	Spring 3.1×20	2	8020 1296 0000
L12	Liner Lower Plate Assy.	1set	0186 0426 0099
	(a) Liner Lower Plate	1	0186 0426 0000
	(b) Pin 3X5	1	8052 1031 0000
L13	Adjust Bolt	1	0444 0522 0000
L14	O-Ring N2	1	9010 4001 0000
L15	Back-up Ring	1	9090 2001 0000
L16	Nylon Bushing	1	0181 0431 0000
L17	Oil Plug	2	0181 0010 0000
L18	O-Ring N2	2	9010 4001 0000
L19	O-Ring P12 (R-ROG11003V)	1	9011 7001 0000
L20	Back-up Ring 12X16X0.8	1	9090 1010 0000
1	Washer 12X15.8X4.8	1	8040 1165 0000
★2	Washer 11.5X16X0.2	1	8041 5046 0000
★3	Washer 11.5X16X0.3	1	8041 5026 0000
★4	Washer 11.5X16X0.4	1	8041 5065 0000
★5	Washer 11.5X16X0.5	1	8041 5022 0000

The part “※” can not be supplied individually.
So please order it as a unit of assembly shown by
arrow mark (↑).

★ Marked parts may not be used, in some case.

Exploded View of Liner Case & Hammer Case



Battery System Wrench with built-in angle sensor

MODELS (YES.No.)	TOOL No.
YS-Z800 (00)	0483 0000 0000
YS-Z800A (00)	0483 0000 0001

Parts for Hammer Case

No.	Name of parts	Per set	parts No.
H	Hammer Case Assy.	1set	0483 0401 0099
H1	Hammer Case	1	0483 0401 0000
H2	Ball Bearing 6901ZZ2CM	1	9100 5026 0000
H3	Main Shaft Assy.	1set	0483 0614 0099
H4	Bearing Case	1	0484 0650 0000
H5	Washer 20.86X27.8X0.5	1	8042 3005 0000
H6	Washer BWW-6001	1	9230 0014 0000
H7	Ball Bearing 6902ZZ1CM	1	9100 5032 0000
★H8	ST-Packing 23X27.6X0.1	1	8011 1174 0000
★H9	ST-Packing 23X27.6X0.2	1	8011 1175 0000
★H10	ST-Packing 23X27.6X0.3	1	8011 1176 0000
★H11	ST-Packing 23X27.6X0.4	1	8011 1177 0000
H12	Wire Circuit Board	1	0480 1611 0000
H13	Screw M3X8	2	9440 2029 0000
H14	Sensor Base Assy.	1set	0446 0345 0199
H15	Screw M3X8	2	9440 2029 0000
H16	ST-Packing 3.4X6.1X0.1	2	8011 1166 0000
H17	Torque Circuit Board Assy.	1set	0480 1607 0099
H18	Contraction Tube SMTFZ-4 4.5mm	1	9380 5143 0000
H19	Screw M3X6	2	9400 2014 0000
H20	Cover Plate	1	0483 0014 0000
H21	Screw M3X10	3	9440 2013 0000
6	Hexagon Socket Bolt M4X14	4	8070 3008 0000
7	Spring Washer M4	4	9200 3012 0000
Standard Accessories			
	TF Pin 2X90	1	8051 6001 0000
8	Protector	1	0483 0029 0000
Parts for YS-Z800A			
H'	Hammer Case <A-Type>	1set	0483 0401 0098
H3'	Main Shaft Assy. <A-Type>	1set	0483 0614 0098
H22	Bit Chuck Assy.	1set	2057 0414 0099
	(a) Bit Chuck	1	2057 0414 0000
	(b) Ball 1/8	1	9150 3009 0000
	(c) Spring 13.5×10	1	8020 1340 0000
	(d) Spring Washer	1	2331 0419 0000
	(e) Retaining Ring 10×1	1	8030 1009 0000

The part “※” can not be supplied individually.
So please order it as a unit of assembly shown by
arrow mark (↑).

★ Marked parts may not be used, in some case.