


I. EXPLODED VIEW

EW-9 - 70



II. SPARE PARTS LIST FOR EW-SERIES SPRING BALANCERS

Index Nos.	Name of Parts	Parts No.							
		EW- 9	EW-15	EW-22	EW-30	EW-40	EW-50	EW-60	EW-70
1	Case	9001	9001	22001	22001	40001	40001	40001	40001
	Suspension Hook Cpl.	9021	9021	22025	22025	22025	22025	22025	22025
2	Suspension Hook	—	—	—	—	—	—	—	—
3	Latch	—	—	—	—	—	—	—	—
4	Latch' Spring	—	—	—	—	—	—	—	—
5	Round Rivet	—	—	—	—	—	—	—	—
6	Suspension Hook Shaft	9019	9019	22023	22023	22023	22023	22023	22023
7	Suspension Hook Rivet	RRC525	RRC525	RRC732	RRC732	RRC732	RRC732	RRC732	RRC732
8	Stopper Pin	9018	9018	22055	22055	40055	40055	40055	40055
9	Stopper Spring	9016	9016	22019	22019	22019	22019	22019	22019
10	Stopper Pin Holder	9015	9015	22017	22017	22017	22017	22017	22017
11	Stop Ring Pin	PPS2.535	PPS2.535	PPS340	PPS340	PPS340	PPS340	PPS340	PPS340

Index Nos.	Name of Parts	Parts No.							
		EW- 9	EW-15	EW-22	EW-30	EW-40	EW-50	EW-60	EW-70
12	Cap	9049	9049	22056	22056	22056	22056	22056	22056
13	Safety Stop Arm	9014	9014	22016	22016	22016	22016	22016	22016
14	Hex Cap Screw	SHC512	SHC512	SHC612	SHC612	SHC612	SHC612	SHC612	SHC612
15	Spindle	9009	9009	22010	22010	40010	40010	60010	60010
16	Key	Unnecessary				40012	40012	40012	40012
17	Worm Wheel	Unnecessary				40011	400011	40011	40011
18	Ball Bearing	Unnecessary		BB6004	BB6004	BB6004	BB6004	BB6004	BB6004
19	Drum	9003	9003	22003	22003	22003	22003	22003	22003
	Self-Contained Spring	9008	15008	22008	30008	40008	50008	60008	70008
20	Spiral Spring	—	—	—	—	—	—	—	—
21	Spring Case	—	—	—	—	—	—	—	—
22	Spring Case Cover	—	—	—	—	—	—	—	—
23	Bushing	9011	9011	22009	22009	40009	40009	60009	60009
24	Hex Bolt	SH510	SH510	SH610	SH610	SH610	SH610	SH610	SH610
25	Hex Bolt	Unnecessary		SH68	SH68	SH68	SH68	SH68	SH68
26	Spring Washer	WS52	WS52	WS62	WS62	WS62	WS62	WS62	WS62
27	Casing Cover	9002	9002	22002	22002	40002	40002	60002	60002
28	Casing Cover Bushing	9013	9013	22015	22015	22015	22015	22015	22015
29	Hex Bolt	SH520	SH520	SH620	SH620	SH620	SH620	SH620	SH620
	Cable Cplt.	9040	9040	22044	22044	22044	22044	22044	22044
30	Cable	—	—	—	—	—	—	—	—
31	Thimble	—	—	—	—	—	—	—	—
32	Load Hook	—	—	—	—	—	—	—	—
33	Load Hook	—	—	—	—	—	—	—	—
34	Load Hook Latch Spring	—	—	—	—	—	—	—	—
35	Round Rivet	—	—	—	—	—	—	—	—
36	Lock (A)	—	—	—	—	—	—	—	—
37	Lock (B)	—	—	—	—	—	—	—	—
38	Collar	9045	9045	22049	22049	22049	22049	22049	22049
39	Rubber Shock Absorber	9046	9046	22050	22050	22050	22050	22050	22050
40	Cable Set-Bolt	PH1/8	PH1/8	PH1/4	PH1/4	PH1/4	PH1/4	PH1/4	PH1/4
41	Thrust Washer	9012	9012	9012	9012	40014	40014	40014	40014
42	Worm	9010 a	9010 a	9010 a	9010 a	40013 a	40013 a	40013 a	40013 a
43	Gage	9039	15039	22043	30043	40043	50043	60043	70043
44	Gage Screw	9038	9038	9038	9038	9038	9038	9038	9038
45	Safety Device Pin	9017	9017	22021	22021	40021	40021	40021	40021
46	Safety Device Spring	9016	9016	22019	22019	40020	40020	40020	40020
47	Safety Device Spring	9015	9015	22017	22017	40018	40018	40018	40018
	Screw	9015	9015	22017	22017	40018	40018	40018	40018
48	Retaining Ring	WRE5	WRE5	WRE5	WRE5	WRE6	WRE6	WRE6	WRE6

Remarks: When ordering spare parts, please specify Index parts No. Name and Applicable Model.