


RRI-3506 DIE GRINDER

Edition 01



Index No	Part No.	Description	Q'ty
1	3506-001-00	Retainer	1
2	3506-002-00	O-ring	1
3	3506-003-00	Valve housing	1
4	3506-004-00	Valve bushing	1
5	3506-005-00	O-ring	1
6	3506-006-00	Valve stem	1
7	3506-007-00	O-ring	1
8	3506-008-00	Spring	1
9	3506-009-00	Regulator valve	1
10	3506-010-00	O-ring	1
11	3506-011-00	O-ring	1
12	3506-012-00	Nut	1
13	3506-013-00	Packing	1
14	3506-014-00	Ball bearing	1
15	3506-015-00	Rear end plate	1
16	3506-016-00	Spring pin	1
17	3506-017-00	Rotor blade	4
18	3506-018-00	Rotor	1

Index No	Part No.	Description	Q'ty
19	3506-019-00	Washer	1
20	3506-020-00	Cylinder	1
22	3506-022-00	Front plate	1
23	3506-023-00	Ball bearing	1
24	3506-024-00	Bevel gear	1
25	3506-025-00	Housing	1
26	3506-026-00	Spring pin	1
27	3506-027-00	Control lever	1
28	3506-028-00	Ball bearing	1
29	3506-029-00	Bevel gear	1
30	3506-030-00	Ball bearing	2
31	3506-031-00	Key	1
32	3506-032-00	Chuck casing	1
33	3506-033-00	Retainer	1
34	3506-034-00	Collet 6 mm	1
35	3506-035-00	Clamp nut	1
36	3506-036-00	Oil cap	1
37	3506-037-00	Wrench 14 mm & 17 mm	2